




FLAT DISPLAY TECHNOLOGY CORPORATION

Smart Graphic Module


How To Update Smart Graphic Module Picture Memory By USB

Smart Graphic Module

1. Smart Graphic Module (SGM)



- (FG0502W001-00R) 5 inches
- (FG064VW001-00R) 6.4 inches
- (FG070WW001-00R) 7 inches
- (FG080SW001-00R) 8 inches
- (FG102WW001-00R) 10.2 inches



- (FG050VW001-00R) 5 inches
- (FG056VW001-00R) 5.6 inches
- (FG104SW001-00R) 10.4 inches

2. SGM Relation Materials


Name	Status
J204	1.Short : update 2.Open : Normal
LED	1.Light : Power is OK 2.OFF : Power Off
LED 101	Flash During The Update
USB 201	USB Port

Name	Status
J301	1.Short : Update 2.Open : Normal
LED101	1.Light : Power is OK 2.OFF : Power Off
LED 201	Flash During The Update
USB 303	USB Port




Smart Graphic Module

3. SGM Update Picture Memory Flow Chart




Smart Graphic Module

4. Update Brief Block



5. Install SGM For Update Picture Memory




Smart Graphic Module

6. LED Signal Status

■ DC +12V Power Signal

Power LED (Green) Indication



■ Smart Graphic Module Update Signal

Update LED (Red) Indication

